

# DHCP Pool

A DHCP pool is a collection of [IP addresses](#) available for [DHCP](#) allocation.

The **Pool Start** number is the first available number in the pool.

The **Pool Size** is the count of available numbers, counting from the pool start.

Example: with Pool Start of 50 and a Pool Size of 100, the available pool addresses are 50 to 150.

From:

<http://docs.intenogroup.com/juci/glossary/> - **Inteno Glossary**

Permanent link:

[http://docs.intenogroup.com/juci/glossary/d/dhcp\\_pool](http://docs.intenogroup.com/juci/glossary/d/dhcp_pool)

Last update: **2018/08/10 18:16**

